



SMSA SNOWPLOWING PROCEDURES

From smsaroads@gmail.com Hotline # 740-339-7510

1. Snow is plowed when 4" has accumulated.
2. If the roads are icy, gravel or sand will be added to those areas.
3. The snowplow travels the roads twice during each call to plow, pushing the snow back as far as possible, plus some work on the intersections.
4. The snowplow will use a rubber edge to save our gravel.
5. If it snows all day long, the snowplow may wait until snowing stops, unless it looks to be getting too deep to handle - in which case, multiple plowings will be made.
6. Ice on steep areas: Gravel or sand will be added to the three hills as needed -
 - a. Sundance,
 - b. Blue Smoke and
 - c. at the end of Shotgun Spring Rd.
7. Gravel bins are placed in 3 locations by steep areas. These should be monitored and kept filled.
8. Roads will be plowed to the exact locations of the 6 shared wells.
 - a. Often overlooked areas are those wells at the ends of private driveways. We ask members to contact smsaroads@gmail.com or call the hotline at 740-339-7510 if those areas have not been plowed.
9. Watching the weather advisory. SMSAROADS will contact the snowplowers to discuss and evaluate the report and have them provide recommendations for handling each situation.